

Allow at least 3/4"(20mm) above the module

Mark for screws here

Allow at least 2.5" (65mm)
below the module for cables

Set your printer properties to print actual size. *Print To Fit* or *Scaled* printing options must not be used.

Use scissors to cut trim the printout if desired. Position the template where desired, then mark the 2 screw holes with a sharp pointed object. Drilling of a pilot hole is recommended.