

Allow at least 3/4"(20mm) above

Mark for screws here

Set your printer properties to print actual size. *Print To Fit* or *Scaled* printing options must not be used.

Allow at least 2.5" (65mm)  
below the module for cables

Use scissors to cut trim the printout if desired. Position the template where desired, then mark the 2 screw holes with a sharp pointed object. Drilling of a pilot hole is recommended.