

Allow at least 1" (25mm)
of space above the DOS

Mark for screws here

Set your printer properties to print actual size. *Print To Fit* or *Scaled* printing options must not be used.

Print, then set your DOS on top of the printout to make sure the printout is the exact same size as the DOS.

Use scissors to cut along the outer edges of the printout. Position the template where desired, then mark the screw hole locations with a sharp pointed object. Drilling of a 1/16" pilot hole is recommended.

Allow 2.5" clearance on left side for the
cable connections

